

Thunderbird Headquarters, Inc.



4020 PIKE LANE
CONCORD, CA 94520

510-825-9550 INFORMATION LINE
510-825-9550 LOCAL ORDER LINE
510-689-1771 FAX LINE

800-227-2174 U.S. TOLL FREE ORDER LINE
800-642-2405 CA. TOLL FREE ORDER LINE

Inspection Stamp Decal Locator 1955-57 Thunderbird

Road Tested - on each door in an area just below garnish
on door edge.

Final Inspection - right inner fender panel in the area
between voltage regulator and generator

Paint Inspection - bottom side of hood on the left hand side
on left frame about 20" from rear (top)
edge. Under dash near headlight switch.

Glass Inspection - on firewall behind battery near ground
cable connection.

Trim Inspection - on firewall right hand side, either side
of hood catch assembly.

Date - on heater core frame, the side that faces battery
(56,57 only)

6 VOLT, 12 Volt - on round motor assembly of the heater
blower

Before applying decals:

- (1.) Clean all surfaces where decals will be applied.
- (2.) Trim decals with scissors to leave 1/16" - 1/8"
border around yellow markings. Do this before
peeling off the backing paper.

To Apply decals:

After trimming as specified above, simply peel off
backing paper and apply to appropriate area.