

Thunderbird Headquarters, Inc.



4020 PIKE LANE
CONCORD, CA 94520-1227

email: tbirdhq@tbirdhq.com
www.tbirdhq.com

925-825-9550 INFORMATION/LOCAL ORDERS
800-227-2174 TOLL FREE ORDERS

925-689-1771 LOCAL FAX
800-964-1957 TOLL FREE FAX

B5482AK INSTRUCTIONS

Remove old sway bar, sway bar brackets and sway bar end link kits

Remove radiator protection plate that was above the original sway bar

Install the new sway bar using the new end link kits, bushings and brackets provided.

Reinstall the radiator protection plate

Note: The new sway bar brackets provided will bolt to the inside of the left and right frame rails using the existing bumper bracket bolts. Also note that the new sway bar will now be above the radiator protection plate.